

# Cleaning of Norski Wildernes | Full Access Norski Toilets | Outdoor Kitchens



## **Initial Clean**

Shock dose with 1Ltr Industrial concetrate down shote.

## **Daily**

### Bio-Zyme Industrial

- Use 120mls of Bio-Zyme Industrial into spray pack and fill with 4Lt of cold water
- Spray down, shute or toilet generously
- Spray walls floors and toilets
- Use brush to scrub shute
- Pour 60mls concetrate down shute on septic waste

#### Bio-Zyme Cleaner

- Use 60mls of Bio-Zyme cleaner and fill 750mls spray bottles
- Spray around toilets cubicle for smell
- Wipe toilets seat and surronds with toilet paper
- Spray Cleaner down shute and leave
- For outdoor kitchen use 60mls/750mls spray bottle of Bio-Zyme Cleaner spray and wipe application

BIO-ZYME IS APPROVED FOR SEPTIC USE





MPI Approved C32 MPI Approved Cleaner | Sanitiser MPI Dairy Approved and Recognised